




# Pièces de rechange Spare parts list


## 5000\*\*02\*\*



*DEBROUSSAILLEUSE  
GRASS CUTTER*



0340040002: Bleu P301 / Blue P301  
 0340040008: Orange RAL2009  
 0340040010: Rouge RAL3001 / Red RAL3001



5002021312: Rouge RAL3001 / Red RAL3001  
 5002025712: Bleu RAL5010 / Blue RAL5010

