

# PARTS LIST

## PS25 FOG KING

### CONTENTS

1. MAIN BODY .....	1 ~ 2
2. CHEMICAL TANK .....	3 ~ 4
3. POWER SPRAYER .....	5 ~ 8
4. REDUCTION GEAR .....	9 ~ 10
5. ENGINE .....	11 ~ 14
6. CARBURETOR, RECOIL STARTER .....	15 ~ 18
7. ACCESSORIES .....	19 ~ 20


2017.03.



**MARUYAMA**


P/N 524454

1. PS25 FOG KING  
MAIN BODY




Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
1-1	355011	PS25FOGKING		
1-2	125966	Throttle Cover	1	
1-3	282365	Throttle Cable	1	
1-4	126722	Buffer	2	22-M6x11x11
1-5	126756	Nut	2	M6
1-6	126722	Buffer	1	22-M6x11x11
1-7	125803	Stay	1	
1-8	126756	Nut	1	M6
1-9	127847	Coil Tube	1	15x18x60L
1-10	104343	Band	1	CV-200
1-11	126178	Cap Screw	4	M5x15
1-12	125277	Nut	3	
1-13	125053	Collar	3	
1-14	127221	Screw	2	M6x16
1-15	126756	Nut	2	M6
1-16	277136	Bracket	2	
1-17	125824	Bolt	4	M6x16(SMK)
1-18	134454	Base	1	
1-19	130181	Stopper	2	
1-20	129268	Spring	2	
1-21	134455	Stay(R)	1	
1-22	134456	Stay(L)	1	
1-23	130420	Tapping Screw	6	M5x25
1-24	125707	Cushion Pad	2	
1-25	125962	Cushion Pad	1	
1-26	125068	Fastener	4	
1-27	100749	Fastener	2	#7
1-28	127019	Knapsack Band	1	
1-29	127221	Screw	2	M6x16
1-30	127224	Washer	2	6x23xt1.6
1-31	127237	Nut	2	M6
1-32	082684	Screw	1	M3x16
1-33	115148	Throttle Lever	1	
1-34	127226	Nut	1	M5
1-35	114895	Stop Button	1	AV0.5x320L
1-36	087785	Cap Screw	1	M5x0.8x20
1-37	126081	Nut	1	M5
1-38	092038	Screw	2	M6x30(MK)
1-39	126756	Nut	2	M6
1-40	114896	Earth Cord	1	
1-41	114901	Vinyl Hose	1	8x9x220

## 2. PS25 FOG KING CHEMICAL TANK




Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
2-1	125692	Chemical Tank	1	
2-2	124250	Cap	1	
2-3	029299	Packing	1	36xt3.0
2-4	131591	Cap, Chemical Tank	1	Incl.5,6
2-5	022363	Inner Cap	1	
2-6	022362	Packing	1	150x170xt10
2-7	131154	Strainer	1	
2-8	134457	Label	1	PS25FOGKING(CAIMAN)
2-9	134553	Label	1	
2-10	134554	Label	1	
2-11	134458	Label	1	EACPS25FOGKING

### 3. PS25 FOG KING POWER SPRAYER



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
3-1	129663	Pump Ass'y	1	Incl.2~53,4-1~4-9
3-2	125673	Crankcase Ass'y	1	
3-3	102683	Oil Seal	2	G16244
3-4	106190	Collar	2	
3-5	121179	Connecting Rod	1	M5
3-6	125680	Sleeve	2	16x33
3-7	102358	Seal Retainer	2	
3-8	112252	Packing	2	
3-9	013977	O-Ring	2	S26
3-10	043426	Suction Valve Seat	2	5x17x2.8
3-11	100441	Piston Packing	2	
3-12	023357	Suction Valve Collar	2	5x8x10
3-13	022023	Suction Valve Stopper	2	5x16x3
3-14	125681	Cap Screw	2	M5x50x22
3-15	015848	Spring Washer	2	M5
3-16	021549	O-Ring	2	P5
3-17	014175	O-Ring	4	P9
3-18	100554	Spacer pipe	2	6x12x10
3-19	103128	Cylinder Head(A)	1	
3-20	102634	Cylinder Head(B)	1	
3-21	013983	O-Ring	2	S31.5
3-22	125682	Cylinder Pipe	2	20x26x22
3-23	023172	O-Ring	2	P22
3-24	125683	Valve Seat	2	
3-25	103575	O-Ring	2	23x1.5
3-26	043723	Discharge Valve	2	16x1.5
3-27	043360	Discharge Valve Spring	2	
3-28	103132	Spring Case	1	
3-29	121618	Spring Retainer	1	
3-30	011682	O-Ring	1	P10
3-31	121620	Compression Coil Spring	1	
3-32	121619	Discharge Valve	1	
3-33	103746	Valve Seat	1	
3-34	011343	O-Ring	1	P10A
3-35	011346	O-Ring	1	P14
3-36	124246	Handle	1	
3-37	127225	Collar	1	8x10x5.3
3-38	127217	Washer	5	8.5x14xt0.5
3-39	126521	Nut	1	M8
3-40	127216	Washer	1	M8
3-41	121956	Screw	8	M5x32(SMK)
3-42	816036	Screw	4	M5x60(SMK)
3-43	125801	Plate	1	
3-44	122175	Hose Ass'y	1	Incl.45
3-45	122177	Tube	1	15.2x19.5x120


### 3. PS25 FOG KING POWER SPRAYER






Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
3-46	103033	Band	2	
3-47	128937	Hose Ass'y	1	Incl.48
3-48	128938	Tube	1	15.2x19.5x330
3-49	103033	Band	2	
3-50	131939	Plug	1	
3-51	021549	O-Ring	1	P5
3-52	129042	Cap	1	
3-53	043972	Band	1	

4. PS25 FOG KING  
REDUCTION GEAR




Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
4-1	126279	Reduction Gear Ass'y	1	Incl.2-8
4-2	125685	Gear Case	1	
4-3	102680	Bearing	2	#6000ZZ
4-4	112184	Bearing	1	6000DDU
4-5	125686	Pinion Gear	1	
4-6	103144	Bearing	1	#6004ZZ
4-7	126280	Crankshaft	1	
4-8	127367	Clutch Drum	1	
4-9	126059	Bolt	4	M6x60(SMK)

# 5. PS25 FOG KING ENGINE




Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
5-1	875093	Engine	1	BE230P/68
5-2	266249	Cylinder	1	New gasket required
5-3	283420	Gasket	1	
5-4	267290	Cap Screw	2	M5x20WSW
5-5	265802	Insulator	1	New gasket required
5-6	267049	Gasket	1	
5-7	265924	Cap Screw	2	M5x25WSW
5-8	282835	Muffler Comp.	1	
5-9	266264	Cap Screw	2	M5x50
5-10	281340	Gasket	1	
5-11	278408	Top Cover Ass'y	1	Incl.12-14
5-12	278409	Top Cover	1	
5-13	286349	Knob Bolt	1	
5-14	286270	Washer	1	M5
5-15	267063	Crankcase	1	
5-16	280488	Bearing	2	6001 C3
5-17	261492	Oil Seal	1	
5-18	261386	Oil Seal	1	
5-19	055185	Snap Ring	1	#28
5-20	261612	Cap Screw	3	M5x30
5-21	281300	Piston	1	
5-22	264891	Piston Ring	2	(2)required
5-23	261036	Piston Pin	1	5.7x8x23.5L
5-24	288520	Bearing, Needle	1	
5-25	261576	Clip, Piston	2	
5-26	267193	Crankshaft/Conn. Rod Ass'y	1	
5-27	264887	Clutch Ass'y	1	Incl.28,29
5-28	264888	Clutch Shoe	2	(2)required
5-29	264889	Spring, Clutch	1	
5-30	264505	Bolt	2	
5-31	261777	Wave Washer	2	
5-32	261189	Washer	2	6x16.5x1.2
5-33	278411	Fan Cover	1	
5-34	261250	Cap Screw	4	M5x20
5-35	269516	Magneto Ass'y	1	Incl.36-42
5-36	261356	Rotor/Fan	1	
5-37	269512	Ignition Coil Ass'y	1	Incl.38-42
5-38	267403	Spark Plug Wire Ass'y	1	Incl.39,40
5-39	261074	Plug Boot	1	
5-40	261075	Connector	1	
5-41	261072	Cap	1	
5-42	269418	Insulator	1	
5-43	261076	Woodruff Key	1	3x10
5-44	261417	Nut, Rotor	1	M8
5-45	280381	Spacer	2	

# 5. PS25 FOG KING ENGINE



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
5-46	261256	Cap Screw	2	M4x25
5-47	262483	Spark Plug	1	BPMR6Y
5-48	267492	Lead	2	130L
5-49	261202	Grommet	1	
5-50	125696	Fuel Tank Ass'y	1	Incl.51-62
5-51	125697	Fuel Tank	1	
5-52	262726	Fuel Tank Cap Ass'y	1	Incl.53
5-53	261105	Gasket	1	
5-54	282630	Fuel Pipe Pick-up Ass'y	1	Incl.55-60
5-55	282629	Fuel Pipe Ass'y	1	Incl.56-58
5-56	265869	Grommet	1	
5-57	261690	Fuel Pipe	1	160L
5-58	263038	Return Pipe	1	3x6x85
5-59	264653	Filter Ass'y	1	
5-60	261117	Clip	1	
5-61	261117	Clip	1	
5-62	261696	Breather Ass'y	1	


6. PS25 FOG KING  
 CARBURETOR, RECOIL STARTER







Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
6-1	282490	Recoil Starter Ass'y	1	Incl.2-13
6-2	281454	Recoil Starter Ass'y	1	Incl.3-9
6-3	269495	Recoil Spring	1	
6-4	280114	Thrust Disk	1	
6-5	281455	Spring Case Ass'y	1	
6-6	280110	Pulley	1	
6-7	281621	Starter Rope	1	
6-8	269501	Washer	1	
6-9	269502	Screw	1	
6-10	269492	Starter Pulley Ass'y	1	
6-11	280808	Grip	1	
6-12	125800	Pipe	1	8x10x390
6-13	125964	Throttle Case Ass'y	1	
6-14	282563	Adapter Ass'y	1	
6-15	265726	Cap Screw	3	M4x16
6-16	280144	Tapping Screw	3	M4x16
6-17	282958	Carburetor Ass'y	1	Incl.18-36
6-18	263739	Pump Body	1	
6-19	262991	Purge Body	1	
6-20	262992	Cover Plate	1	
6-21	261874	Primer Bulb	1	
6-22	283905	Diaphragm, Meterring	1	
6-23	262993	Gasket	1	
6-24	262994	Diaphragm, Fuel Pump	1	
6-25	282576	Gasket	1	
6-26	268574	Main Jet	1	
6-27	261871	O-Ring	1	
6-28	261876	E-Ring	1	
6-29	261658	Swivel	1	
6-30	261875	Screw	2	
6-31	264677	Bracket	1	
6-32	261878	Nut	1	M6
6-33	261877	Adapter	1	
6-34	262996	Screw	4	
6-35	261657	Packing	1	
6-36	264678	Washer	1	
6-37	261864	Gasket	1	
6-38	284821	Case Ass'y	1	Incl.39-45
6-39	269026	Case Body	1	
6-40	284802	Valve	1	
6-41	284803	Lever	1	
6-42	284816	Washer	1	6.4x11x0.15
6-43	269032	Screw	1	M3.5x8
6-44	126993	Nut	1	M5x0.8
6-45	269051	Sleeve	2	5.5x7.1x3

# 6. PS25 FOG KING CARBURETOR, RECOIL STARTER



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
6-46	261814	Cap Screw	2	M5x50WSW
6-47	269030	Element	1	
6-48	269027	Air Creaner Cover	1	
6-49	286349	Knob	1	
6-50	278417	Bracket	1	
6-51	261607	Cap Screw	2	M5x16WSW
6-52	134451	Label	1	

# 7. PS25 FOG KING ACCESSORIES



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
7-1	118267	Hose Ass'y	1	Incl.2,3
7-2	013572	Hose Ass'y	1	11.5x16xt1.5
7-3	074369	Hose Ass'y	1	6.5x11.5x1.5t
7-4	105891	Ball Cook	1	G1/4xG1/4
7-5	124042	Nozzle Pipe Ass'y	1	Incl.6,7
7-6	112850	Hose Ass'y	1	11.5x15.5xt1.5
7-7	112851	Hose Ass'y	1	7x11xt1.5
7-8	117958	Wide Nozzle Ass'y	1	Incl.9-12
7-9	103170	Nozzle Pipe	1	
7-10	103171	Hose Ass'y	2	
7-11	118266	Nozzle Plate	2	
7-12	103173	Cap	2	
7-13	134459	Instruction Manual	1	PS25FOGKING
OPTION				
7-14	127037	Discharge Valve	1	
7-15	127038	Discharge Valve Ass'y	1	Incl.16-27
7-16	103132	Spring Case	1	
7-17	121618	Spring Retainer	1	
7-18	011682	O-Ring	1	P10
7-19	121620	Compression Coil Spring	1	
7-20	121619	Discharge Valve	1	
7-21	103746	Valve Seat	1	
7-22	011346	O-Ring	1	P14
7-23	107198	Handle	1	
7-24	127225	Collar	1	8x10x5.3
7-25	127217	Washer	5	8.5x14xt0.5
7-26	126521	Nut	1	M8
7-27	127216	Washer	1	M8